

Анаэробная перчаточная камера серии 888

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: pbf@nt-rt.ru || сайт: <https://plas-labs.nt-rt.ru/>

CHAMBERS AND GLOVE BOXES

AUTOMATIC “PLC” CONTROLLED ATMOSPHERE ISOLATOR/GLOVE BOX (ANAEROBIC CHAMBER)

This chamber has been designed for automatic atmosphere control when working with Oxygen sensitive materials, product containment needs, and/or general isolation control. The chamber features an internal “PLC” control system with multifunctional operator interface.

This glove box is perfect for working in anaerobic conditions.

Features included are:

- Internal “PLC” control system.
- Three (3) drying train canisters filled with Molecular Sieve™ and quick dis-connects.
- White ambidextrous Hypalon™ gloves.
- Two (2) 1/4” hose barb (tubing) gas connections.
- “Bright Light” system (40,000 hour lamp guarantee).
- Programmable Catalyst Heater unit with two (2) Palladium (Pd) filled canisters.
- Multiple electric outlet (socket) strip. UL, CSA, and CE approved.
- Two (2) ground key cock valves for purging the main chamber.
- Standard 24 month warranty (Not gloves or consumables).

The operator can program these features:

- The number of purging cycles.
- Gas selection (inert or anaerobic blend).
- Drying train reaction time frame.
- Pressure “hold” function.
- Anaerobic gas reaction time frame.
- Selection of chamber to be purged (Main or transfer).

“PLC” Control Board close up



The operator interface continually displays the “PLC” functions and working pressures within the main chamber or transfer chamber. It can also support an additional 4-20 mAmp analog input. These inputs are used to create your own unique atmosphere chamber. Examples are percentage of O₂ analyzer, humidity information, etc.



SIMPLICITY-888 & SIMPLICITY-888/EXP
With Catalyst Heater Unit and Palladium Canisters

Product Specifications

Inside Dimensions	41" w x 28" d x 26" h 1,040 mm x 712 mm x 660 mm h
*Outside Dimensions	55" w x 35" d x 38" h 1,400 mm x 890 mm x 965 mm h
Approximate Volume	17.3 Cubic Feet 489 Liters
Electrical Requirements	N. American 115-120 Volts, 60 Hz. 10 Amps. Export Model 220-240 Volts, 50 Hz. 5 Amps.
Maximum Working Pressure	6.0" of H ₂ O 1.49kPa
Approximate Shipping (crated) weight	250 Pounds 112.5 Kilos

*Includes transfer chamber.



#800-HEATER w/#800-PC

The programmable Catalyst Heater has two basic functions. It reduces trace amounts of Oxygen that enter the main chamber and it maintains incubation temperatures from ambient up to 42 degrees C.

*Refer to Accessories Section for more details about this device.



По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04	Иваново (4932)77-34-06	Магнитогорск (3519)55-03-13	Ростов-на-Дону (863)308-18-15	Тольятти (8482)63-91-07
Ангарск (3955)60-70-56	Ижевск (3412)26-03-58	Москва (495)268-04-70	Рязань (4912)46-61-64	Томск (3822)98-41-53
Архангельск (8182)63-90-72	Иркутск (395)279-98-46	Мурманск (8152)59-64-93	Самара (846)206-03-16	Тула (4872)33-79-87
Астрахань (8512)99-46-04	Казань (843)206-01-48	Набережные Челны (8552)20-53-41	Санкт-Петербург (812)309-46-40	Тюмень (3452)66-21-18
Барнаул (3852)73-04-60	Калининград (4012)72-03-81	Нижний Новгород (831)429-08-12	Саратов (845)249-38-78	Ульяновск (8422)24-23-59
Белгород (4722)40-23-64	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Севастополь (8692)22-31-93	Улан-Удэ (3012)59-97-51
Благовещенск (4162)22-76-07	Кемерово (3842)65-04-62	Ноябрьск (3496)41-32-12	Саранск (8342)22-96-24	Уфа (347)229-48-12
Брянск (4832)59-03-52	Киров (8332)68-02-04	Новосибирск (383)227-86-73	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Владивосток (423)249-28-31	Коломна (4966)23-41-49	Омск (3812)21-46-40	Смоленск (4812)29-41-54	Чебоксары (8352)28-53-07
Владикавказ (8672)28-90-48	Кострома (4942)77-07-48	Орел (4862)44-53-42	Сочи (862)225-72-31	Челябинск (351)202-03-61
Владимир (4922)49-43-18	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Ставрополь (8652)20-65-13	Череповец (8202)49-02-64
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Сургут (3462)77-98-35	Чита (3022)38-34-83
Вологда (8172)26-41-59	Курск (4712)77-13-04	Петрозаводск (8142)55-98-37	Сыктывкар (8212)25-95-17	Якутск (4112)23-90-97
Воронеж (473)204-51-73	Курган (3522)50-90-47	Псков (8112)59-10-37	Тамбов (4752)50-40-97	Ярославль (4852)69-52-93
Екатеринбург (343)384-55-89	Липецк (4742)52-20-81	Пермь (342)205-81-47	Тверь (4822)63-31-35	

Россия +7(495)268-04-70	Казахстан +(727)345-47-04	Беларусь +(375)257-127-884	Узбекистан +998(71)205-18-59	Киргизия +996(312)96-26-47
-------------------------	---------------------------	----------------------------	------------------------------	----------------------------